

ExactFit - Magnetic Phone Mount

BMW E46

READ BEFORE INSTALLATION

The use of any Rennline product is the sole responsibility of the end user. Rennline Inc. accepts no responsibility for warranty voids or damage resulting from the use of these products. Due to the varying location of wiring harnesses and other components, carefully inspect any area prior to drilling. All Rennline products are intended for off road use only and should be installed by a qualified automotive technician.



Photo 1

- Part List:
 (1) Mounting Bracket - P/N - PM17
 (1) P/N - PM01
 - Aluminum Ball
 - Magnetic Pad Assembly
 - Steel pads
 (1) Thread-Locking Alloy Button Head Socket Cap Screw - 10/32 x .5" - MC92360A248

1. Install the aluminum ball onto the metal bracket as shown using the supplied screw.
2. Pry the trim panel located below the passenger side airbag and above the radio with a plastic trim removal tool. (Photo 2)
3. Remove the nut next to the top right corner of the radio with a 10mm socket. (Photo 2)
4. install the Exact-Fit phone mount as shown and reinstall the nut. (Photo 3)
5. Reinstall all the plastic trim and screws in reverse order of disassembly. (Photo 5)
6. Attach the phone to your mount.
7. Enjoy your new Rennline product.

Photo 2



Photo 3



Photo 4



Photo 5

