

**ExactFit - Magnetic Phone Mount**

BMW F30

**READ BEFORE INSTALLATION**

The use of any Rennline product is the sole responsibility of the end user. Rennline Inc. accepts no responsibility for warranty voids or damage resulting from the use of these products. Due to the varying location of wiring harnesses and other components, carefully inspect any area prior to drilling. All Rennline products are intended for off road use only and should be installed by a qualified automotive technician.



**Part List:**

- (1) Mounting Bracket - P/N - PM19
- (1) P/N - PM01
  - Aluminum Ball
  - Magnetic Pad Assembly
  - Steel pads
- (1) Thread-Locking Alloy Button Head Socket Cap Screw - 10/32 x .5" - MC92360A248

1. Install the aluminum ball onto the metal bracket as shown using the supplied screw.
2. Gently lever out and pull the center dashboard vent trim panel. Leave the panel resting on the dashboard. (Photo 1)
3. Remove the panel below the the climate control by pulling down from the top. (Photo 2)
4. Remove the four Torx T20 screws (red arrows)from the corners of the radio trim. (Photo 3)
5. Install the Exact-Fit phone mount to the back the radio panel as shown. Ensure the mounting holes are aligned. (Photo 4)
4. Reinstall the four Torx T20 screws on the corners of the radio panel. (Photo 5)
5. Reinstall all the plastic trim in reverse order of disassembly. (Photo 6)
6. Attach the phone to your mount.
7. Enjoy your new Rennline product.

Photo 1



Photo 3



Photo 5



Photo 2



Photo 4



Photo 6

