

READ BEFORE INSTALLATION

The use of any Rennline product is the sole responsibility of the end user. Rennline Inc. accepts no responsibility for warranty voids or damage resulting from the use of these products. Due to the varying location of wiring harnesses and other components, carefully inspect any area prior to drilling. All Rennline products are intended for off road use only and should be installed by a qualified automotive technician.

INSTALLATION INSTRUCTIONS FOR RUBBER GRIP PEDAL SET

Check to make sure that you have all parts listed prior to installation. If anything is missing contact us immediately.

- (4) #8/32X5/8" Black S/S Truss Head Screw - MC91770A196
- (4) #8/32 S/S Nylon Nut - MC90101A009
- (4) Rubber grips

Step 1 (Brake)

- A. Remove factory rubber pedal pad.
- B. Determine mounting holes based on any obstructions behind the factory pedal limiting the installation of hardware. We supply hardware for up to 4 mounting points per pedal. Most people choose 2 to 3 depending on model.
- C. Remove the rubber grips from the mounting holes.
- D. Place aluminum pedal cover over the top of the factory pedal .
- E. Mark holes for mounting
- F. Center punch and drill holes.
Note: drill with a 3/16" bit
- G. Install Rennline pedal cover using the supplied stainless screws and nuts.

